



HA360M-II Weather Bundle Quick Start Guide

Setting Up Your HomeAware™ Main Unit for the First Time

Remove all contents of the box.

- HA360M-II - Main Unit
- HA360SA2.1 - Security Alert
- HA360V-II - Bed Shaker
- Midland NOAA Weather Radio

Connect Power Supply and Bed Vibrator

Plug the cord from the HomeAware-II's power supply into the 5.1V 2A DC IN connector on the back of the HomeAware and then plug the power supply into a 120V outlet.

Plug the cord of the vibrator into the Vibrator jack on the rear of the HomeAware-II. The vibrator can be placed under either the pillow or mattress. If it is under the pillow, the vibration will be stronger, but it could fall off the bed during the night and you might not feel the vibration in the case of an emergency. If the vibrator is placed under the mattress, the vibration may be weaker but there is less risk of it falling away.



Install Rechargeable Battery

Remove the battery cover from the bottom of the HA360M-II. Fully insert the battery connector into the matching socket inside of the battery compartment. Push until you feel or hear a click to let you know it is in all the way. Insert the battery into the battery compartment, taking care not to unplug or put stress on the battery cable. Reinstall the battery cover and make sure it clicks into place.



Setting the Time of Day

Press the **TIME SET** button. Blinking red dots shown on the display indicate time set mode has been activated. Press the **HOURLY** buttons up or down and the **MINUTES** buttons up or down to set desired time. The PM indicator is located on the top left-hand side. Press the **ENTER** button when done to complete the time setting. The display dots will stop blinking to indicate the time has been set.

For additional information refer to the HA360M-II, HA360SA2.1 and Midland NOAA Weather User Guides.



HA360M-II Weather Bundle Quick Start Guide

Setting up your HA360SA2.1 for the First Time

Install provided batteries into the bottom of the unit. Once installed push the link button and the red LED light will light. If the light does not show, you may have the batteries in backwards. Leave battery door opened to link the HA360SA2.1 to the Main Unit. Press **SET UP** button on the Main unit and the word **LINK** will be shown on the display, press **ENTER** Link will be blinking. Press and release the link button. **PICK DEVICE** will display on the screen, press the blue **TONE** button until **STORM** is displayed. Press the **ENTER** button to complete.



Connecting the HA360SA2.1 to your Midland NOAA Weather Radio

Plug the 3.5mm cable into the **EXTERNAL ALERT** port on the back of the Midland Weather Radio. Plug the other end of 3.5mm cable into the outlet on the side of the HA360SA2.1. There are three switch positions on the back of the HA360SA2.1. When using with the Midland Weather Radio the switch should be in the N / open center position.



Setting up your Midland NOAA Weather Radio for the First Time

NOAA Weather Radio Quick Setup

1. Place 3 AA alkaline batteries (not supplied) into the compartment on the underside of radio.
(Note: Batteries provide approximately 5 hours of emergency power or 75 hours of standby power for the radio in case of a power outage).
2. Plug the AC Adapter into a standard outlet. Plug the other end of the adapter into the DC jack on the back of the radio.
3. Pull out antenna and extend to its full length.
4. Ensure ON/OFF switch is in the ON position
5. WELCOME will be displayed.
6. To SET LANGUAGE press the SELECT button then:
7. Choose your language by pressing ▲ or ▼ then press the SELECT button.
8. To SET LOCATION press the SELECT button then:
9. Choose location type ANY then press SELECT.
(Note: see page 8 for more programming instructions).
10. To SET TIME press the SELECT button then:
11. Set the time by using ► ▲ ▼ or then press SELECT.
12. To SET CHANNEL press the SELECT button then:
13. Tune the channel to the desired broadcast by using ▲ or ▼.
14. Adjust the volume by using the VOLUME UP or VOLUME DOWN button.
15. To complete setup press the SELECT button.

NOTE: To reset the radio to the factory defaults, press and hold the WEATHER / SNOOZE button while turning on the unit.